CALIBRATION FOR RMA

#1	Description
CR	Calibration for RMA

#2	Calibration Type Selection
5	Calibrate At Specific Points
6	Premium Calibration
6C	CVD Calibration (RTD Only)

#3	Certification Options
G	Guide 17025 Certification
T	Calibration Tag
Z	Standard NIST Traceable

#4	Sensor Type		
J	Type J	F	RTD_385_200
T	Type T	G	RTD_385_500
K	Type K	H	RTD_427_10
E	Type E	I	RTD_672_120
N	Type N	Q	RTD_3916_100
R	Type R	Y	RTD_3926_100
S	Type S	NS	Type N & S Thermocouple
C	Type C	NR	Type N & R Thermocouple
B	Type B	KN	Type K and N Thermocouple
3	RTD_385_100	KR	Type K and R Thermocouple
M	RTD_385_1000	KS	Type K and S Thermocouple

#5	Number of Elements
S	Single Element
D	Dual Element
T	Triple Element

#6	Sensor Tolerance		
1	Class A	5	+/- 0.74C at 0C
2	Class AA	6	Special
3	Class B	7	Standard
4	1/10 DIN B		

#7	RMA Number
R_____	State RMA Number

#8	Box Number
B____	State Box #

CR	5	Z	E	D	6	R787	B124